

GOOD SITE PRACTICE

FOR FILM FACED PLYWOOD USED AT A CONSTRUCTION SITE

1. BEFORE USE

- Store the film faced plywood in a roofed area. There should be no rain or direct sunlight on the plywood.
- The storage place should not be too dry or too hot as well.
- Plywood must not be placed in contact with the ground. Use crates under each pack.
- Don't move the panels with forklifts after the strappings are removed.

2. IN USE

- Our film faced plywood are delivered with 4 edges painted. If the panels are cut or drilled all cuttings should be painted immediately.
- Formwork plywood should be oiled before each use.
- Even though the phenolic film contains certain amount of release agent, it is necessary that panels should be used with good quality release agent.
- Panels should be fastened to formwork support from the reverse side with screws. Shank nails are not recommended.

3. AFTER USE

- Clean the plywood carefully. Dry and reoil the panel immediately.
- Use plastic or nylon tools to clean concrete residues from the plywood surface.
- Store the plywood with the film away from sunlight as the exposure can lead to quick loss of moisture of face veneer and damage to the phenolic film overlay.
- Fill scratches and holes with filler.
- Plywood can be recycled.

PREPARED BY [YALONG WOOD](#)

FOR FURTHER INFORMATION CONTACT SALES@YALONGWOOD.COM